


SMOKED DOME COVER**C-A711DM**

Thank you for purchasing TOA's Smoked Dome Cover. Please carefully follow the instructions in this manual to ensure long, trouble-free use of your equipment.

**1. SAFETY PRECAUTIONS**

- Be sure to read the instructions in this section carefully before use.
- Make sure to observe the instructions in this manual as the conventions of safety symbols and messages regarded as very important precautions are included.
- We also recommend you keep this instruction manual handy for future reference.

**CAUTION**

Indicates a potentially hazardous situation which, if mishandled, could result in moderate or minor personal injury, and/or property damage.


Attach the Smoked Dome Cover to the camera securely. Failure to do so could result in the cover falling and possibly causing personal injury.

2. GENERAL DESCRIPTION

The TOA's C-A711DM Smoked Dome Cover is exclusively designed to be used in conjunction with the optional C-CC714 and C-CC764 Combination Cameras for outdoor use.

3. INSTALLATION

Detach the pre-installed transparent cover from the camera, and attach the Smoked Dome Cover instead. For attaching procedures, refer to the installation manual supplied with the Camera.



4. SPECIFICATIONS

Finish	Cover: PC resin, Light gray Dome: PC resin, Smoked (Transmission factor: 30%)*
Dimensions	ø219.8 x 115 (H) mm (Dome: ø150 mm)
Applicable Camera	C-CC714, C-CC764

* The object illumination of the camera equipped with the C-A711DM needs approximately 3.3 times that of the C-CC714 and C-CC764 Camera with the pre-installed dome cover.

Note: The design and specifications are subject to change without notice for improvement.