




























































DSP preset list for TOA MA-725F / MM-700F

BANK	DIP SW	PRESET	ROTARY	NAME
1		1		Flat
1		2		Loudness 1
1		3		Loudness 2
1		4		Loudness 3
1		5		Bass Boost 1
1		6		Bass Boost 2
1		7		Bass Boost 3
1		8		High Cut 1
1		9		High Cut 2
1		10		High Cut 3
1		11		Subwoofer LPF 1
1		12		Subwoofer LPF 2
1		13		Subwoofer LPF 3
1		14		Full Range with Subwoofer 1
1		15		Full Range with Subwoofer 2
1		16		Full Range with Subwoofer 3

BANK	DIP SW	PRESET	ROTARY	NAME
2		1		Flat
2		2		F-122C
2		3		F-122C Low-cut
2		4		Subwoofer for F-122C
2		5		SR-S4
2		6		HX-5
2		7		HX-5 Low-cut
2		8		FB-120
2		9		F-1522SC
2		10		F-2322C
2		11		F-2352C
2		12		F-2852C
2		13		SR-H2S
2		14		SR-H3S
2		15		HS-1200
2		16		HS-1500

BANK	DIP SW	PRESET	ROTARY	NAME
3		1		Flat
3		2		Acoustic
3		3		Bass Booster
3		4		Bass Reducer
3		5		Classical
3		6		Dance
3		7		Deep
3		8		Electronic
3		9		Hip Hop
3		10		Jazz
3		11		Latin
3		12		Lounge
3		13		Piano
3		14		Pop
3		15		R&B
3		16		Rock

BANK	DIP SW	PRESET	ROTARY	NAME
4		1		Flat
4		2		Spoken Words
4		3		Treble Booster
4		4		Treble Reducer
4		5		Vocal Booster
4		6		F-1000
4		7		F-1300
4		8		F-2000
4		9		H-1
4		10		H-2
4		11		H-3
4		12		SR-H2L
4		13		SR-H3L
4		14		CS-64
4		15		CS-154/304
4		16		PC-580RU/RVU